



The engine model number is **engraved into the engine block on the flat side opposite the spark plug**. The model number will start with a 'LMH', 'PLMH', 'PLX' or 'PW'. The model number is the first two of three lines of information in this area.

